

81200データジェネレータにおいて、GP-IB経由で外部からVEEやBASIC等でコントロールできますか？

Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Portions of this software are licensed by third parties including open source terms and conditions.

For detail information on third party licenses, see [Notice](#).

81200データジェネレータにおいて、GP-IB経由で外部からVEEやBASIC等でコントロールできますか？

Contents

81200データジェネレータにおいて、GP-IB経由で外部からVEEやBASIC等でコントロールできますか？

できます。ただし、工場出荷設定ではできませんので、設定を行なって下さい。

以下の例は、81200アプリケーション・ソフトウェアのバージョンがVer2.00の場合です。

1. 81200のデスクトップ画面から、「81200 Configuration」で、「Controlled」を選択し、「Build Systems」を行ないます。
2. 一度、81200からログアウトし、再度81200が起動しますと「HP-IB to HP81200 Getway」となり、外部からコントロール可能となります。
3. もし、できない場合には、「HP-IB to HP81200 Getway」の「HP-IB Settings」で「Termination charactor」を確認して下さい。

