

Technical Support
Knowledge Center Open

Keysight VEE用の計測器ドライ
バがない場合、どうやって計測
器を制御するのですか？

Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Portions of this software are licensed by third parties including open source terms and conditions.

For detail information on third party licenses, see [Notice](#).

Keysight VEE用の計測器ドライバがない場合、どうやって計測器を制御するのですか？

Contents

Keysight VEE用の計測器ドライバがない場合、どうやって計測器を制御するのですか？

ドライバがない計測器でも、Direct I/Oを使用すれば、制御できます。

計測器パネルドライバは、主に計測器のフロントパネル操作に準じたインタラクティブな使用法のために開発されたものなので、実際の自動計測のプログラムでは使用せずに、初期設定や簡単な動作確認をするといった面では有効だといえます。一方、Direct I/Oはドライバを介さない分、処理速度があげられることも可能になりますので、自動計測のプログラミング向きだといえます。

ドライバサポートしていない計測器の制御はもちろん、自動計測のプログラムにも、ぜひDirect I/Oでコントロールされる事をお薦めします。

