

Technical Support  
Knowledge Center Open

# 如何与83752A一起使用\*LRN?命令?

# Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

## Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

**Portions of this software are licensed by third parties including open source terms and conditions.**

**For detail information on third party licenses, see [Notice](#).**

## Contents

如何与83752A一起使用\*LRN?命令？

随产品附送的VEE程序中,讲述了如何使用\*LRN?命令来上载83752设备的状态或把设备状态下载到设备。

右键点击文件名依次选择 File(文件)-> Save Target As (目标另存为) : **83752A\_LRN.vee**

如果您没有安装VEE, 您可以要求或下载这个软件的鉴定拷贝件 : **Keysight VEE Pro**

