

Technical Support
Knowledge Center Open

我可以下載 Keysight GPIB 介面的驅動程式嗎？

Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Portions of this software are licensed by third parties including open source terms and conditions.

For detail information on third party licenses, see [Notice](#).

我可以下載 Keysight GPIB 介面的驅動程式嗎？

Contents

我可以下載 Keysight GPIB 介面的驅動程式嗎？

在設定 GPIB 介面前，您需要將 Keysight IO Libraries 安裝至您的個人電腦。您可以 [從 IO Libraries 備份檔下載](#)。

對於每一種儀器，不論您使用的是安捷倫硬體 I/O 產品（包括 Keysight GPIB 卡和 Keysight I/O 轉換器）和 Keysight T&M Toolkit 的開發套件或自安捷倫取得有效授權的 Keysight VEE Pro，安捷倫都受予您一套免費的 IO Libraries 套裝軟體。

如需特定 I/O 介面與作業系統建議採用何種版本的安捷倫 IO Libraries 的比較資料，請 [參閱安捷倫 IO Libraries 介面支援 Matrix \(55KB PDF\)](#)。

注意：不像一般 PC 介面產品，您在連接 GPIB 介面之前需要安裝 Keysight IO Libraries 至您的 PC。若您沒有安裝 IO Libraries 就連接介面，則 PC 可能無法辨識介面。

