

Technical Support
Knowledge Center Open

키사이트 GPIB 인터페이스용 드
라이버를 다운로드할 수 있습니
까?

Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Portions of this software are licensed by third parties including open source terms and conditions.

For detail information on third party licenses, see [Notice](#).

키사이트 GPIB 인터페이스용 드라이버를 다운로드할 수 있습니까?

Contents

키사이트 GPIB 인터페이스용 드라이버를 다운로드할 수 있습니까?

GPIB 인터페이스를 구성하기 전에 애질런트 IO Libraries를 PC에 설치해야 합니다. 이 라이브러리를 [IO Libraries Archive](#)에서 다운로드할 수 있습니다.

애질런트의 유효한 라이선스가 있는 모든 개별 계측기, 애질런트 하드웨어 I/O 제품(애질런트 GPIB 카드 및 애질런트 I/O 컨버터 포함) 및 애질런트 T&M Toolkit 또는 애질런트 VEE Pro의 개발 사본에 대해, 애질런트는 IO Libraries Suite 소프트웨어의 비독점적인 라이선스 1개를 무료로 제공합니다.

특정 I/O 인터페이스 및 운영 체제에 권장되는 애질런트 IO Libraries 버전 비교는 [Keysight IO Libraries Interface Support Matrix \(55KB PDF\)](#)를 참조하십시오.

참고: 일반 PC 인터페이스 제품과 달리 GPIB 인터페이스를 구성하기 전에 애질런트 IO Libraries를 PC에 설치해야 합니다. IO Libraries를 설치하지 않고 인터페이스를 연결할 경우 PC에서 인터페이스를 인식하지 못할 수 있습니다.

