

Technical Support  
Knowledge Center Open

# 34970A: Scanning from a Computer

# Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

## Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

**Portions of this software are licensed by third parties including open source terms and conditions.**

**For detail information on third party licenses, see [Notice](#).**

## Contents

Yes.

The Keysight 34970A is shipped with both an HP-IB (IEEE-488) interface and an RS-232 (serial) interface for computer control.

Also included with the Keysight 34970A is the Keysight BenchLink Data Logger software. You can also use other programming languages, such as VEE, LabVIEW, C++, and Visual Basic, to program the Keysight 34970A using the SCPI (*Standard Commands for Programmable Instruments*) commands provided.

**For More Information:**

Keysight 34970A User's Guide

- To establish communication over the HP-IB or RS-232 interface, see page 150.
- To establish communication over a serial modem, see page 274.

Keysight E2050A Installation and Configuration Guide:

- For more information on configuring the Keysight E2050A LAN/HP-IB Gateway, see the *Installation and Configuration Guide* included with the product.

Revision 1.0 19 Apr 99 dah

