

Technical Support
Knowledge Center Open

E2120A : VEE에서 GPIB card를 인식시키려면 어떻게 해야 합니 까?

Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Portions of this software are licensed by third parties including open source terms and conditions.

For detail information on third party licenses, see [Notice](#).

Contents

E2120A : VEE에서 GPIB card를 인식시키려면 어떻게 해야 하나요?

VEE에는 PC내의 모든 GPIB card와 card에 연결된 장비를 찾는 기능이 있습니다.

VEE 실행 후, 메뉴바에서 I/O 메뉴를 클릭합니다. "Instrument manager"를 클릭합니다. Instrument Manager Dialog Box에 "My Configuration"이라는 폴더가 디스플레이되고, 모든 VEE로 access 가능한 모든 interface와 계측기 목록이 나열됩니다.

만약 처음으로 VEE가 실행되는 것일 경우, 시스템에 존재하지 않는 몇가지 계측기 목록이 예)와 같은 이름으로 보일수도 있습니다. 예) "dmm(hp34401)@(NOTLIVE)" 시스템에 존재하지 않는 장비들이므로 그 목록들을 삭제하거나 VEE의 찾기기능으로 연결된 계측기를 찾아야 합니다.

목록의 맨 마지막 계측기를 선택한 후, Configuration section의 "Delete Instrument"를 클릭하십시오. 모두 삭제한 후 Instrument List에 "My Configuration"만 남으면 Create I/O Object에서 "Find Instrument"를 클릭하십시오. 잠시 후, VEE는 시스템에 configure된 모든 Interface와 계측장비들을 인식합니다.

만약 설정이 변경되면, VEE에서 연결된 장비를 다시 인식시켜야 합니다. Instrument Manager Dialog Box를 열고, "My Configuration"을 클릭한 후, "Find Instruments"(또는 "Refresh")를 클릭하시면 됩니다.

