

Technical Support
Knowledge Center Open

VEE 7가 지원하는 인터페이스는 무엇입니까?

Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Portions of this software are licensed by third parties including open source terms and conditions.

For detail information on third party licenses, see [Notice](#).

Contents

VEE 7가 지원하는 인터페이스는 무엇입니까?

VEE 7가 지원하는 인터페이스는 다음과 같습니다.

- 애질런트 82357A USB/GPIB 인터페이스
- 애질런트 E5810A 또는 E2050A/B LAN/GPIB 게이트웨이
- 애질런트 82350A/B 또는 82341C GPIB 인터페이스
- TMC 프로토콜을 지원하는 계측기에 USB 연결
- 표준 RS-232
- VXI-11 프로토콜을 지원하는 계측기에 LAN 연결
- NI 488 버전 1.5(또는 이상)을 사용하는 NI I/O 하드웨어

