

Technical Support  
Knowledge Center Open

# VEE에서 IEEE-488 패스 컨트롤을 어떻게 합니까?

# Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

## Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

**Portions of this software are licensed by third parties including open source terms and conditions.**

**For detail information on third party licenses, see [Notice](#).**

## Contents

VEE에서 IEEE-488 패스 컨트롤을 어떻게 합니까?

Windows용 VEE 에서 약간의 제약은 있지만, 패스 컨트롤이 가능합니다.

비활성화 컨트롤러에 Talk 하기 위해서는 인터페이스 동작 다이어그램을 사용 해서 TCT(Take Control) IB 명령 바이트를 보낸다. 예를 들어 비활성화 컨트롤러가 5번으로 지정되었다면, 다음과 같은 패스 컨트롤 을 사용할 수 있다.

```
+-----+
| Start |
+---+---+ |
+---+-----+-----+---+
| = | Interface Op's: hpib7@7 | x |
+---+-----+-----+---+
| |[SEND UNL ]| |
| |[SEND UNT ]| |
| |[SEND TALK 5 ]| |
| |[SEND CMD 9 ]| | <-- TCT byte
+---+-----+-----+---+
```

그 활성 컨트롤러는 제어권을 VEE로 전달 할 수 있거나, 혹은 VEE에서는 IB IF C(Interface clear)라인을 가져오기 위해 **ABORT** 명령을 수행할 수 있다.

```
+-----+
| Start |
+---+---+
|
+---+-----+-----+---+
| = | Interface Op's: hpib7@7 | x |
+---+-----+-----+---+
| |[EXECUTE ABORT ]| |
| | | |
| | | |
| | | |
```

+---+-----+---+

이 내용은 VEE가 시스템 컨트롤러로 동작하고 있음을 가정하며, 82341 카드를 VEEWin 에만 적용됩니다.  
82335 카드는 IFC를 액세스하지 못하므로 해당이 안됨을 알려드립니다.

