

Technical Support
Knowledge Center Open

**VEE：我要如何利用VEE來查看
我的串列埠？**

Notices

© Keysight Technologies Incorporated, 2002-2020

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Portions of this software are licensed by third parties including open source terms and conditions.

For detail information on third party licenses, see [Notice](#).

Contents

VEE：我要如何利用VEE來查看我的串列埠？

首先，確定您已經在I/O Libraries中設定好您的串列埠。進到Start-> Programs-> I_O Libraries-> I_O Config。在Available Interfaces中選取RS-232，然後按一下Configure。設定您選擇的設定值，並記下RS-232 Serial Configuration Window中的 "Logical Unit" 值。這是VEE將要使用的串列介面的位址。按一下OK。在I/O Config上按一下OK。

其次，開啟VEE，並按I/O-> Instrument manager。按一下Find Instruments（在VEE 4.x中為"Refresh"），並記下介面名稱。串列介面的數字，必須與 I/O Config底下的Logical Unit（COM1通常為1）相符。如有必要，可修改該值，以便與I/O Config中的Logical Unit值相符。

Revision 1.0 07 Jan, 2000 rfh

